

# Saturn<sup>®</sup>

## LINT REMOVER

### ST-CC1548



[GB]

LINT REMOVER

Dear Buyer! We congratulate you on having bought the device under trade name "Saturn". We are sure that our devices will become faithful and reliable assistance in your housekeeping.


Avoid extreme temperature changes. Rapid temperature change (e.g. when the unit is moved from freezing temperature to a warm room) may cause condensation inside the unit and a malfunction when it is switched on. In this case leave the unit at room temperature for at least 1.5 hours before switching it on. If the unit has been in transit, leave it indoors for at least 1.5 hours before starting operation.

IMPORTANT SAFEGUARDS

Before Use Please read contents of this manual carefully before any operation. This item requires 2 "AA" batteries. Please, take out batteries, if you are not using the item for a long period of time. Service life – 2 years.

OVERVIEW OF THE COMPONENTS:

- 1. ON/OFF switch
2. Battery compartment
3. Transparent lint container
4. Protection cap



INSTRUCTION FOR USE

Lay your clothes on a flat level surface, preferably an ironing board or pad. Open the battery cover, insert

the batteries according to the polarity marking and close the battery cover. Push on "ON" switch and begin to shaver lint or fuzz off your clothes. The clear fluff box will collect lint and fibers, removed from clothes and can be easily removed to discard the lint and fibers.

CARE AND CLEAN

Please, check the polarity of the batteries to make sure they are in right positions. Check the batteries power to make sure they do not need to be replaced with new ones. Inspect the blade and net by gently pressing on the net to make sure the blades and net are not hitting each other.

Turn the operating switch "OFF" and remove the batteries. Carefully use a flat edge screwdriver or coin and push the blade net from side to open. Take out the blade and clean lint and fibers with the brush. Replace the blade on the axis of motor and carefully rotate it slightly and firmly. Put the blade net on the body and push it into position.

ATTENTION

Not for use by children. The item cannot be used as an ordinary electrical beard shaver. Don't use the item to shave delicate clothing. Do not clean this item with water or other chemical solutions. To be used with alkaline batteries.

PARTS

- Safety Metal Mesh Grill
Safety Blade Cover
Removable Transparent Lint Tank
Blade Diameter: 44 mm

Set

- LINT REMOVER.....1
INSTRUCTION MANUAL WITH WARRANTY BOOK..... 1
PACKAGE.....1




ENVIRONMENT FRIENDLY DISPOSAL

You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.

The manufacturer reserves the right to change the specification and design of goods.

[RU]




"Saturn".

Faint, mostly illegible text, possibly bleed-through from the reverse side of the page, containing some symbols like parentheses and arrows.

1,5

1,5



: 44

2

(“ / »)



“OFF”

.....1  
.....1  
.....1

C

- 2

- 1.
- 2.
- 3.
- 4.



UA

: 44

“Saturn”.

.....1  
.....1  
.....1

(« / »),

“ON”

# Saturn®

## INTERNATIONAL MANUFACTURER'S WARRANTY

MEZINÁRODNÍ ZÁRUKA

GB

### INTERNATIONAL MANUFACTURER'S WARRANTY

The Warranty is provided for the period of 2 years or more if the Law on User Right of the country where the appliance was bought provides for a greater minimum warranty period.

All terms of warranty comply with to the Law on Protection of the Consumer Rights and are governed by the legislation of the country where the product was bought. The warranty and free of charge repair are provided in any country where the product is delivered to by Saturn Home Appliances or authorized representative thereof, and where no restriction of import or other legal provisions interfere with rendering of warranty services and free of charge repair.

#### **Cases uncovered by the warranty and free of charge repair:**

1. Guarantee coupon is filled in improperly.
2. The product has become inoperable because of the Buyer's nonobservance of the service regulations indicated in the instruction.
3. The product was used for professional, commercial or industrial purposes (except for the models, specially intended for this purpose that is indicated in the instruction).
4. The product has external mechanical damage or damage caused by penetration of the liquid inside, dust, insects and other foreign objects.
5. The product has damages caused by non-observance of the rules of power supply from batteries, mains or accumulators.
6. The product was exposed to opening, repair or modification of design by the persons, unauthorized to repair; independent cleaning of internal mechanisms etc. was made.
7. The product has natural wear of parts with limited service life, expendables etc.
8. The product has deposits of scale inside or outside of fire-bar elements, irrespective of used water quality.
9. The product has damages caused by effect of high (low) temperatures or fire on non-heat resistant parts of the product.
10. The product has damages of accessories and nozzles which are included into the complete set of product shipment (filters, grids, bags, flasks, cups, covers, knives, sealing rings, graters, disks, plates, tubes, hoses, brushes, and also power cords, headphone cords etc.).

**On the warranty service and repair, please contact the authorized service centers of "Saturn Home Appliances".**

**MEZINÁRODNÍ ZÁRUKA**

Záruka se poskytuje na dobu 2 roky. V případě že Zákon na ochranu spotřebitele dané zemí umožňuje delší dobu, prodlužuje se záruka na tuto dobu.

Veškeré záruční podmínky odpovídají Zákonu o ochraně práv uživatelů a jsou řízené zákonodárstvím státu, kde byl výrobek koupěn. Záruka a bezplatná oprava se poskytují v každém státě, kam jsou výrobky dodané společností „Saturn Home Appliances“ nebo jejím zplnomocněným zástupcem a kde nejsou žádná omezení na dovoz nebo jiné právní předpisy omezující poskytnutí záručního servisu a bezplatné opravy.

**Případy, na které se záruka a bezplatná oprava nevztahují**

1. Záruční list je vyplněn nesprávně.
2. Výrobek byl poškozen kvůli tomu, že zákazník nesplnil pravidla použití, která jsou uvedena v návodu.
3. Výrobek byl používán k profesionálnímu, komerčnímu nebo průmyslovému cíli (kromě modelů speciálně určených pro tyto účely, což je uvedeno v návodu).
4. Výrobek má viditelné mechanické poškození nebo poškození, vyvolané tím, že se dovnitř dostala tekutina, prach, hmyz a jiné cizí předměty.
5. Výrobek má poškození, která jsou vyvolána nesprávným napájením od baterií, sítí nebo akumulátorů.
6. Výrobek rozebírali, opravovali nebo modifikovali jeho konstrukci lidé, kteří nebyli zplnomocněni k opravě, bylo provedeno samostatné čištění vnitřních mechanismů a pod.
7. Výrobek má proložené potrubí díly s omezenou dobou použití, spotřebních materiálů atd.
8. Výrobek má vrstvu usazeniny uvnitř nebo zvenku termoelektrických ohříváčů, bez ohledu na kvalitu používané vody.
9. Výrobek má poškození, která jsou vyvolána působením vysokých (nízkých) teplot nebo ohně na termonestabilní části výrobku.
10. Výrobek má poškozené příslušenství a nástavce, které jsou dodané spolu s výrobkem (filtry, sícky, sáčky, bačky, mísy, víka, nože, šlehače, struhadla, kotouče, talíře, trubky, hadice, kartáče a také síťové šňůry, sluchátkové šňůry atd.).

**V otázkách záručního servisu a oprav se obraťte na autorizovanou servisní střediska společnosti „Saturn Home Appliances“.**

«Saturn Home Appliances»

- 1.
- 2.
- 3.
- 4.
- 5.
- 6.
- 7.
- 8.
- 9.
- 10.

«Saturn Home Appliances».

					<b>LCD</b>		
.4	" "	8-988-993-37-78	+		+	+	+
18		8(8553) 32-22-11 8-960-047-22-11	+	+	+	+	+
98	« - »	8(86133) 6-09-84, 8-918-215-57-75	+	+	+	+	+
48, .108	" - "	8(3955) 67-00-44, 8(3955) 56-61-77	+	+	+		+
, .109	-	8(86152)2-81-99	+	+	+	+	+
.1, .1, 12	« -29»	8(8182) 44-15-55	+				
, .47	« »	8(8512)25-19-39 8(8512) 25-12-00	+	+	+		
16, 2 .7	« - »	8(8512) 54-67-67, 8(8512) 54-91-91				+	+
.15	« - »	8(85141) 3-61-25	+	+	+	+	+
32		8-927-552-47-21, 8-937-122-13-99				+	+
.113	« »	8(3852) 63-94-02	+		+	+	+
.25		8-905-425-60-4-73	+	+	+		

. .37	-	8(8635) 47-47-72, 8(8635) 47-47-72	+	+	+	+	+
. .63	« - »	8(86155)3-11-00, 8-918-980-64-75	+	+	+	+	+
.84		8(86559) 2-08-02, 8(86559)5-29-71	+	+	+	+	+
. .58	« »	8(8442) 23-41-36, 8(937) 717-93-34	+		+		
. .173	« - »	8(8442) 97-50-10, 8-960-883-59-00			+		
. .4		8(8442) 98-16-47, 8(8442) 53-06-04	+	+	+	+	+
, - ,	« - »	8-961-688-53-48			+		
, .9		8-927-521-52-00			+		+
.32		8-937-722-68-12					+
.158		8-937-730-66-03			+		+
		8-904-404-14-55					+
. .C . 12/15	«Master»	8-928-126-63-66	+			+	

77- .65	« »	8(937) 717-93-36	+		+		
.65	« »	8(8172) 70-03-45, 8(8172) 54-21-54	+		+	+	+
.1	« »	8(8172) 52-72-51	+		+		
.46	" "	8(473) 260-09-08, 8(473) 240-57-73	+		+	+	
140/1	-	8(87951) 6-47-93, 8-928-654-28-01			+		
.48	« »	8-962-655-20-00	+	+	+	+	+
.68	« »	8(8313) 21-14-14	+		+		
.54	« »	8(8313) 20-93-00, 8(8313) 20-92-94			+		
.63	" - "	8(84235) 2-86-59, 8(84235) 9-14-64	+		+	+	+
.84	« »	8(86132) 2-11-71, 8(86132) 3-66-02	+	+	+	+	+
.64	" - "	8(343)240-26-60	+		+		
.16	/ " - "	8(343) 201-51-41, 8(343)347-76-83	+	+	+	+	+

47	« »	8(47467) 4-12-08, 8(47467) 4-33-17	+		+		
.45/6	« - »	8(4932) 335185, 8(4932) 335236	+	+	+	+	+
.4	« - »	8(3412) 3079-79, 8(3412)30-83-07	+		+	+	+
.76	« - »	8(3412) 78-76-85, 8(3412) 78-06-64	+		+	+	+
7/1, 301, 307	« - »	8(3412) 44-60-40, 8(3412) 44-60-67			+		
7 ( « » )	« 26» -	8(86545) 2-74-74			+		
.24	« - »	8(8362) 24-11-24, 8(8362) 25-55-40	+	+	+	+	+
.20	« »	8(39520) 65-04-95, 8(39520) 93-16-56	+		+	+	
.24	" "	8(3952) 42-55-76, 8(3952) 78-15-83	+		+		
.38	« »	8(843) 248-71-17, 8(843) 258-85-65	+		+		
.25, .47	« - »	8 (4842) 54-82-22, 8 (4842) 54-83-33	+	+	+	+	+
33	-	8(3439) 39-95-20, 8(34399)34-74-40	+	+	+	+	+

53/2	-	8(3842) 35-39-67	+			+	
.42	« - »	8(8332) 56-25-95, 8(8332) 54-70-77	+		+	+	
, , 9	-	8-988-548-24-36	+	+	+		
5	« - »	8(4942) 300107, 8(4942) 300107	+		+	+	+
, .2,	-	8(86142)4-43-59	+	+	+	+	+
, 3	-	8(861) 267-50-88	+	+	+	+	+
103, .55	« - - »	8(861) 222-64-13, 8(861) 222-85-55, 8-905-408-08-38	+	+	+	+	+
.42/2	-	8-918-041-31-04, 8(86131) 71-2-72			+		+
, .116	-	8(86164) 7-01-22			+		
, .57	" " -	8(86145) 3-78-74	+	+	+	+	+
, .25	« - »	8(86164) 65-4-95, 8-918-355-81-70	+	+		+	+
, .1	-	8(86153) 4-16-70			+		

168	" - "	8(86151) 4-33-54, 8-918-464-00-86	+	+		+	+
1	« - »	8(3912) 93-54-33, 8(3912) 94-52-82	+	+	+	+	+
36- , .37-	« +»	8 (4712) 50-85-90, 8 (4712) 35-04-91	+	+	+	+	
, .2	« - »	8 (86169) 7-39-99, 8(86169) 7-24-96	+	+	+	+	+
.66	" "	8(4742) 33-45-65, 8(4742) 33-45-95	+	+	+	+	+
, .29	« - »	8 (8772) 52-36-90	+	+	+	+	
25	« - »	8 (8772) 55-62-38			+		+
.20	« - »	8( 8722) 93-30-73	+	+	+	+	+
11	« »	8(86385) 2-33-26 8-960-458-07-11	+	+		+	+
, .16, .9	« - »	8 (499) 340-29-89, 8 (499) 733-25-00			+		
1534	« - »	8(499) 717-82-07, 8(499) 717-82-12	+			+	+
( . . )	« »	8(495) 721-30-70, 8(499) 168-05-19, 8(499) 168-47-15	+			+	+



№ 20 (30/05)	« »	8(8552) 359002, 8(8522) 359042	+	+	+		
№ 24	" - "	8(8662) 42- 04-30 8(8662) 42- 12-21	+		+	+	
№ 55	« - »	8(86554) 5- 59-77, 8(86554) 3- 67-57	+	+	+	+	+
№ 9 ( « »)	« »	8(8555) 48- 08-80, 8-917- 906-60-06	+		+	+	+
№ 21	« - »	8(831) 229- 63-66, 8(831) 229-60-87	+		+	+	
№ 18	« - »	8(831) 46-18- 848		+			+
№ 6	« - »	8(831) 46-18- 848		+			+
№ 18	« - »	8 (3843) 20- 31-33	+		+	+	+
№ 14	« - »	8(8617) 63- 11-15, 8(8617) 63- 03-95	+	+	+	+	+
№ 17	" - "	8(383)274- 99-33, 8(383) 274-99-45	+		+		
№ 24		8(86369) 3- 74-75, 8-928- 609-35-85	+	+	+		
№ 4		8 (3532) 36- 87-94	+			+	+
№ 16	« - »	8(3532) 77- 67-64 , 8(3532) 78- 15-82	+	+	+	+	+

№ 130	" - "	8(3812)36- 42-02	+		+	+	+
№ 2	« - +»	8(3537) 33- 84-43, 8(3537) 35- 13-18	+	+	+	+	+
№ 2	« »	8(8412) 26- 09-60, 8(8412) 26- 12-29	+		+	+	+
№ 3	« - »	8 (342) 221- 40-99	+	+	+	+	+
№ 11	« - »	8(8142) 78- 06-93, 8(8142) 70- 65-48	+		+		
№ 11	« - »	8 (8112)-53- 86-30, 8 (8112)-53-86- 50	+		+		
№ 12		8(793) 31-84- 16	+	+	+	+	+
№ 5-13	" "	8(8793) 98- 70-11	+	+	+	+	+
№ 148		8(47396) 48- 911	+	+	+	+	+
№ 37	« - »	8(863) 250- 47-77	+		+		
№ 50-1/52, 55	« »	8 (863) 21- 92-112, 8- 800-100-51- 52	+	+	+	+	+
№ 11 /17		8-906-453- 35-81	+		+		

12	« - »	8(4855) 22-04-77, 8(4855) 25-38-60	+	+	+	+	+
14	" "	8(86370) 2-19-50	+	+	+	+	+
12	" - "	8(4855) 22-04-77, 8(4855) 25-38-60	+	+	+	+	+
21	« - »	8(4855) 24-31-21	+	+	+	+	+
14, 1	« - »	8(4912) 76-88-01, 8(4912) 40-30-30	+	+	+	+	+
42" "	« - »	8(4912) 41-33-02,	+	+	+	+	+
52, 8, 9		8(846) 931-85-46	+	+	+	+	+
63	" - "	8(846) 379-54-54	+	+	+	+	+
197	« - XXI»	8(812) 600-11-97	+	+	+	+	
41,	« - »	8(812) 325-36-56, 8(812) 325-36-57	+		+	+	
11, 36	« -95»	8(812) 822-18-00, 8(812) 320-06-61	+				
1	« - »	8(8342) 23-05-91, 8(8342) 47-48-59	+	+	+		

3-	« - »	8(8452) 35-11-80, 8(8452) 55-43-63	+	+	+	+	+
167/1		8-951-522-38-11	+	+	+	+	+
253	« - »	8(496) 547-04-95, 8(496) 549-32-79	+	+		+	+
90	« - »	8 (8622)55-51-19, 8 (8622) 55-01-08	+			+	+
50	« - »	8(8652) 74-01-91	+	+	+		
63	« - »	8(8652) 24-30-14, 8(8652) 23-31-81	+	+	+	+	+
15	« - »	8(8652)95-53-68, (8652)95-61-90			+		
1	« - »	8 (4725) 24-62-27, 8 (4725) 24-73-49	+	+	+		
158	« - »	8(3473) 20-12-13, 8(3473) 20-27-70	+			+	+
25	« - »	8(8212) 22-95-29, 8(8212) 29-12-20	+	+	+	+	+
137	« -2000»	8(4752) 56-19-42, 8(4752) 56-19-44	+	+	+	+	+
88/15	-	8-910-834-80-35, 8-952-065-89-10	+			+	

№ 24/2	-	8(86130) 4-86-59, 8-918-147-02-03	+	+	+	+
№ 2/2	"	8(86196) 7-20-53	+	+	+	+
№ 48	« +»	8(8482) 22-72-41, 8(8482) 22-71-85, 8(8482) 61-65-64	+	+	+	+
№ 58	« -2»	8(3822) 56-23-35, 8(3822) 48-08-80	+		+	
№ 137	« -»	8(4872) 31-12-57	+	+	+	+
№ 55	"	8(3452) 47-35-69	+		+	+
№ 28	« »	8(3012) 21-89-63	+		+	+
№ 18, 2	« »	8(8422) 31-00-00	+	+	+	+
№ 16/7	« -»	8(8422) 73-44-22, 8(8422) 73-29-19	+	+	+	+
№ 378	« -»	8(87875) 7-44-82	+	+	+	
№ 148	« -»	8(3472) 77-12-62	+		+	
№ 153, 42, 7	« »	8(347) 279-90-70, 8(347) 241-62-02				+
№ 15	"	8(86391) 2-18-06	+		+	

№ 36	« -»	8(8352) 62-30-97, 8(4942) 63-20-98	+		+	
№ 102 ( )	-	8(351) 772-72-05, 8(351) 772-73-66, 8(351) 772-69-01	+	+	+	+
№ 8 ( )	-	8(351) 239-39-34, 8(351) 239-39-35	+	+	+	+
№ 18	« »	8(8202) 54-31-88	+		+	+
№ 340" "	« -»	8(8782) 27-30-60, 8(8782) 27-70-77	+	+	+	+
№ 48, 11	" ."	8(8782) 25-04-66, 8(8782) 25-19-15	+	+	+	+
№ 1	-	8-904-345-83-18	+	+	+	+
№ 3-21	« -»	8 (84722) 9-52-07, 8-937-469-52-07	+	+	+	+
№ 57	« -»	8(8453) 55-80-89, 8-964-848-45-06	+		+	+
№ 12	« -»	8 (4852) 25-94-83	+		+	

UA

2

«Saturn Home Appliances»

- 1.
- 2.
- 3.
- 4.
- 5.
- 6.
- 7.
- 8.
- 9.
- 10.

«Saturn Home Appliances».

				/	-	-
					-	-

1	,36	Hi-Fi	(064) 424-89-50	+	+	+
2	.14		(065)632 21 83, 050-904-57-17	+	+	+
3	,66		062744-60- 38(39)	+	+	+
4	,49	-	(04563) 633-19	-	+	-
5	.50- ,82	-	(045) 63-68-413	+	+	+
6	,57	-	(041) 43-406-36	+	+	-
7	,43	" "	(0314 1) 43-432	+	+	+
8	,3, .8	-	(044) 332-01-67	+	+	+
9	,42	-	(0432) 46-50-01	+	+	-
10	,61		(0432) 61-95-73	+	+	+
11	,16	-	(0432) 464393; (0432) 468213	+	+	+
12	,3		(0432) 64-24- 57, (0432) 64-26-22	+	+	+
13	,1		(0432) 509-191, 579-191	+	+	+
14	,68, 1 ,420		(0562) 337-574	+	+	+
15	17 .130	-	(056) 778-63-25 (28)	+	+	+
16	,59		(0562) 35-04-09	+	+	+
17	,118		(0562) 67-60-44	+	+	+
18	,41		(056) 790-04-60	+	+	+

19	,9		(068) 851-33-33	+	+	+
20	188		(062) 3450607 0953204451	+	+	+
21	,129		(062) 349-26-81	+	+	+
22	,1	-	(062) 3027569 (066)5082652	+	+	+
23	,8	" "	(0412) 471-568	+	+	-
24	,4 .222		(067) 410 2198	+	+	+
25	24	C	(0412) 47-07- 42, 42-11-53	+	+	-
26	,50	-	(061) 220-97-65 (64)	+	+	+
27	,175		(061) 701-65-96	+	+	+
28	,83		(061)212-03-03	+	+	+
29	,75		066-085-75-39	+	+	+
30	19		(0342)559-525, 750-777	+	+	+
31	14		(0342) 754737	+	+	-
32	,9	-	096-729- 4038,067-484- 9888	+	+	+
33	,76		(04597) 57393	+	+	-
34	,161	-	(04736) 629-49	+	+	+
35	1	-	(044) 591-11-90	+	+	+

36	,1	" "	(044) 4269198	+	+	-
37	,9 .57	-	(044) 369-5001 (063) 486-6999	+	+	+
38	,10		(06272) 2-62- 23, (050) 279-68-16	+	+	+
39	,1	" "	(0522) 301-456	+	+	+
40	,2		(0522) 35-79-23	+	+	+
41	,98	-	(0522) 270- 345,349-585	+	+	+
42	,13		(097) 264-21- 67, 776-67-70	+	+	+
43	,3, .5	" "	(04142) 5-05-04	+	+	+
44	,15-106		(06264) 5-93-89	+	+	+
45	,7		(050) 526-06-68	+	+	+
46	,44, .1		(05366) 39-192	+	+	-
47	,42		(056) 401-33- 56, 404-00-80, 474-61-03	+	+	+
48	,9		(056) 4092302 03	+	+	+
49	,64/7		(0564) 40-07-79	+	+	+
50	,73	" "	(056) 440-07-64	+	+	+
51	,81		(050) 214-91- 73; (066) 017- 02-03	+	+	+
52	,49	-	(0642) 505-783	+	+	+
53	,50		(0642)50-57-83	+	+	+

54	' ,96 -		(0642) 494-217, 33-11-86	+	+	+
55	' ,1	-	(0332)290752	+	+	+
56	' ,15 -		(032) 244-53-44	+	+	+
57	' 35	" -	(032) 2973631	+	+	+
58	' 2		(032) 247-14-99	+	+	+
59	' ,116	" -	(032) 245-80-52	+	+	-
60	' ,28		(032) 239-51-52 (032) 239-55- 77,295-50-28, 295-50-29	+	+	+
61	' ,9	" "	032-267-63-26	+	+	-
62	' 242		(062)322-55-50	+	+	+
63	' ,2	-	04337- 64847;0432- 468213	+	+	+
64	' ,24/1		(099) 262-11-18	+	+	+
65	' ,46		(03131)37-337, 37-336	+	+	-
66	' .50 ,32/18		(0629) 41-06-50	+	+	+
67	' ,227	" -	(0629) 473-000	+	+	+
68	' ,33,	" "	(0512) 580-555	+	+	+
69	' 49	" "	0512-58-21-80	+	+	+

70	' ,2		(0512) 58-06-47	+	+	+
71	' ,62	-	(05662) 22-488, (097) 402-71-95	+	+	-
72	' ,97, .2	" ' - "	(05662) 4-15-03	+	+	-
73	' 38		(055) 497-26-17	+	+	-
74	' ,38	" "	(041)4152010	+	+	-
75	' 66 ( . 2)		048-7317704; 7317703;	+	+	+
76	' 90		(048) 700 17 37	+	+	+
77	' ,55	" "	(048) 715-10- 25, (0482) 39- 06-18	+	+	+
78	' ,67	" "	8(05632) 6-15- 54, (05632) 6- 23-42	+	+	-
79	' ,26		050-013-72-17, 0532-509889	+	+	+
80	' 14		(0532) 69-42-62	+	+	+
81	' 21	-	(0532) 69-09-46 (093)562-81-25	+	+	+
82	' 66	-	(0532)615-621	+	+	+
83	' ,371	-	(04637)53-982 (093)753-38-28	+	+	+
84	' ,101/1		(046) 3738595	+	+	+
85	' ,12	-	(0362) 26-67- 53,26-65-85	+	+	-

86	, , 26		(0692) 55-56-43, 45-36-99	+	+	+
87	, 72	-	(0652)-69-07-78	+	+	+
88	, 17/1	" - "	(0652) 522-771	+	+	+
89	, 32	-	(04733)-46-182	+	+	-
90	15 ( , . )		(06444)40289	+	+	+
91	, 171 /10	-	(245) 53-136	+	+	+
92	, 19		(0542) 705-296	+	+	-
93	, 17	SLT- Service	(0542) 78-10-13	+	+	+
94	, 2	" "	(0352) 26-30-13, 23-17-97	+	+	-
95	, 1/24	" "	(047) 44-46-614,(047) 44-46-134	+	+	+
96	, 101		(0312) 661-297	+	+	+
97	, 12		(057) 717-13-39, 702-16-20	+	+	+
98	, 3		(057) 734-97-24, 712-51-81	+	+	-
99	18 ( , - 42 )	" "	(096) 595-37-46	+	+	+
100	, 1		(03142) 42-258	+	+	+
101	, 5	-	(0552) 29-60-42	+	+	+
102	, 28		(0552) 43-40-33	+	+	+
103	, 35		(0552) 420-235	-	-	+

104	, 18		(0382)78-37-55, 78-37-73	+	+	+
105	, 10/1	-	(0382) 723-241, 723-240	+	+	+
106	, 63		097-549-20-36	+	+	+
107	, 7, . 301		0472-633-728	+	+	+
108	, 71	-	(0472) 435-389	+	+	+
109	146, . 102	" - "	(0472) 563-478, 500-354, (096) 505-63-63	+	+	+
110	, . 77- , 1		(0462) 601585	+	+	+
111	, 6		(0462) 724872,724949	+	+	+
112	, 105 ( )		(0372) 55-48-69,90-13-11	+	+	+
113	, 265		(0372) 58-43-01	+	+	+
114	, 3	" - "	(050) 373-73-71	+	+	+
115	, 5 ( . )		(050) 324-43-01	+	+	-

GB

WARRANTY COUPON

When purchasing the product, please require its checking before you; BE SURE that the goods sold to you, are functional and complete and that the warranty coupon is filled in correctly.

This warranty coupon confirms the absence of any defects in the product you purchased and provides for free of charge repair of the product failed through the fault of the manufacturer throughout the period of warranty service and free of charge repair.

Failing the presentation of this coupon, in case of its improper filling in, infringement of factory seals (if any), and also in cases indicated in the warranty obligations, the claims are not accepted, and no warranty service and free of charge repair is made! The warranty coupon is valid only in the original copy with the stamp of trading organization, signature of the seller, date of sale and signature of the buyer.

CZ

ZÁRU NÍ LIST

P i koupi výrobku žádejte o jeho vyzkoušení ve Vaší přítomnosti, P ESVD TE SE, že Vám prodaný výrobek je dobře fungující a kompletní a že záru ní list je vyplněn správně.

Tento záru ní list potvrzuje, že na Vámi koupeném výrobku nejsou žádné vady a zajišťuje bezplatnou opravu nefungujícího přístroje z viny výrobce, během celé záru ní doby.

Bez předložení tohoto listu, při jeho nesprávném vyplnění, porušení plomb výrobce (jsou-li na výrobku) a také v případech, které jsou uvedené v záručním listě, nároky se nepřijímají a záruční oprava se neprovádí! Záruční list je platný jenom jako originál s razítkem obchodní organizace, podpisem prodávajícího, termínem prodeje a podpisem zákazníka.

RU

UA



# Saturn®

WARRANTY COUPON

ZÁRU NÍ LIST

SATURN HOME APPLIANCES S.R.O. KON VOVA 141, 13083  
PRAHA 3 – ŽIŽKOV, ES KÁ REPUBLIKA, TEL: + 4202/ 67 108 392

Model /

Production number/Výrobní íslo/  
/

Date of sell/Termín prodeje/ / ,

Shop stamp/Razítko obchodu/ /

Seller's signature/Podpis prodava e/ /

Buyer's Signature confirming the acquaintance and consent with conditions of free of charge maintenance service of the product, and absence of the complaints on appearance and color of the product.  
Podpis zákazníka, potvrzující seznámení a souhlas s podmínkami bezplatného záru ního servisu výrobku, a také neexistence nárok na vn jšek a barvu výrobku.

<b>Saturn®</b> Model / / ..... Production number / / ..... ..... Name of the Trade Company / / ..... ..... Stamp of the Trade Company/ / ..... ..... Client Address/Phone # / / ..... ..... Date of Receiving/ / ..... ..... Defect / / ..... Signature, Stamp / , / ..... ..... <b>COUPON 1</b>	<b>Saturn®</b> Model / / ..... Production number / / ..... ..... Name of the Trade Company / / ..... ..... Stamp of the Trade Company/ / ..... ..... Client Address/Phone # / / ..... ..... Date of Receiving/ / ..... ..... Defect / / ..... Signature, Stamp / , / ..... ..... <b>COUPON 2</b>	<b>Saturn®</b> Model / / ..... Production number / / ..... ..... Name of the Trade Company / / ..... ..... Stamp of the Trade Company/ / ..... ..... Client Address/Phone # / / ..... ..... Date of Receiving/ / ..... ..... Defect / / ..... Signature, Stamp / , / ..... ..... <b>COUPON 3</b>
---	---	---