

Saturn®

ST-HC7217 NEW

HAIR DRYER



GB

HAI R DRYER

Dear Buyer!

We congratulate you on having bought the device under trade name "Saturn". We are sure that our devices will become faithful and reliable assistance in your housekeeping.

Avoid extreme temperature changes. Rapid temperature change (e.g. when the unit is moved from freezing temperature to a warm room) may cause condensation inside the unit and a malfunction when it is switched on. In this case leave the unit at room temperature for at least 1.5 hours before switching it on.
If the unit has been in transit, leave it indoors for at least 1.5 hours before starting operation.

PARTS INDICATION



- | | |
|-----------------------------|------------------|
| 1. Air Exit Grill | 6. Cool/warm/hot |
| 2. Air Inlet Grill | 7. Handle |
| 3. Nozzle | 8. Power Cord |
| 4. Cool switch | 9. Hanging Loop |
| 5. Off/low-speed/high-speed | |

Safety measures

1. Connect the dryer to 220-230 V outlet.
2. Never use in the bathtub, shower or over a filled sink.
3. Do not use solvents, detergents / cleaners or abrasive materials to clean the device.
4. Never lay it down on a pillow or

blanket when in use.

5. Make sure that the air inlet and air exit grills are free when using the unit. The dryer is protected against overheating. If the air inlet is accidentally covered, the dryer will stop automatically. Switch off and allow to cool down for a few minutes before attempting to restart.

6. Disconnect after use.
7. Children are not aware of potential hazards. Do not allow children to operate this appliance.
8. Service life – 2 years.

Using the dryer

When making up your hair, you can use this one with concentrator nozzle.

1. There are two switches (0/I/II) on the handle. One (above) regulates the speed of the motor (and thus the airflow), by pressing the I or II, I file for a slow, II file for high speed, O file for turning off the power supply. The other switch (below) regulates three different temperatures, 0 for cool wind, I for warm and II for hot.
2. After washing, towel your hair and then use the dryer. Plug in appliance and select the switch position for the right temperature and airflow.
3. Once your hair is dry set the switch off "0" position and unplug the dryer.
4. Select the cool shot position. Using cool shot has a good protection on hair, which has been dried and made up.

Cleaning your dryer

Please always disconnect your dryer before cleaning.

Do not immerse in water.
From time to time remove dust and hair from the air inlet grill with a small brush.

You can clean your appliance with a slightly damp cloth and dry it up with a dry cloth.

Warning:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use this appliance near water in bathtubs, basins or other vessels.
- Do not pull the cord with unnecessary force. Do not damage or

modify the cord. If the supply cord is damaged, it must be replaced by the manufacturer service agent in order to avoid a hazard.


➤ Correct disposal of this product. This product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Technical Data:

Power: 2000 W
Rated voltage: 220-240 V
Rated frequency: 50 Hz
Rated current: 9

Set
HAIR DRYER 1
INSTRUCTION MANUAL WITH
WARRANTY BOOK 1
PACKAGE 1


ENVIRONMENT FRIENDLY DISPOSAL
You can help protect the environment!
Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.



The manufacturer reserves the right to change the specification and design of goods.

RU

"Saturn".



- 1.
- 2.
- 3.
- 4.
- 5.
- 6.
- 7.
- 8.
- 9.

1. 220-230
- 2.
3. /
- 4.
- 5.

- 6.
- 7.
8. - 2
1. / () (0/I/II).
II - 2. (I), O - II, (II), O - ()
II - 3. «O»
4.

2000
:220-240
50
9 A

1
C
1
1



5.


»

9.

.....1

U

"Saturn".



1. 220-230

2.

3.

4.

5.

»

(

6.

7.

»

»

8. - 2

1.

/ (0/I/II).

»

2.

I / (I),
II, O - (0 -)

II -

2000
220-240
50
9

.....1

.....1

1,5

1,5



1.

6.


3.

«0»

4.

7.

8.



GB

INTERNATIONAL MANUFACTURER'S WARRANTY

The Warranty is provided for the period of 2 years or more if the Law on User Right of the country where the appliance was bought provides for a greater minimum warranty period.

All terms of warranty comply with the Law on Protection of the Consumer Rights and are governed by the legislation of the country where the product was bought. The warranty and free of charge repair are provided in any country where the product is delivered to by Saturn Home Appliances or authorized representative thereof, and where no restriction of import or other legal provisions interfere with rendering of warranty services and free of charge repair.

Cases uncovered by the warranty and free of charge repair:

1. Guarantee coupon is filled in improperly.
2. The product has become inoperable because of the Buyer's nonobservance of the service regulations indicated in the instruction.
3. The product was used for professional, commercial or industrial purposes (except for the models, specially intended for this purpose that is indicated in the instruction).
4. The product has external mechanical damage or damage caused by penetration of the liquid inside, dust, insects and other foreign objects.
5. The product has damages caused by non-observance of the rules of power supply from batteries, mains or accumulators.
6. The product was exposed to opening, repair or modification of design by the persons, unauthorized to repair; independent cleaning of internal mechanisms etc. was made.
7. The product has natural wear of parts with limited service life, expendables etc.
8. The product has deposits of scale inside or outside of fire-bar elements, irrespective of used water quality.
9. The product has damages caused by effect of high (low) temperatures or fire on non-heat resistant parts of the product.
10. The product has damages of accessories and nozzles which are included into the complete set of product shipment (filters, grids, bags, flasks, cups, covers, knives, sealing rings, graters, disks, plates, tubes, hoses, brushes, and also power cords, headphone cords etc.).

On the warranty service and repair, please contact the authorized service centers of "Saturn Home Appliances".

INTERNATIONAL MANUFACTURER'S WARRANTY

MEZINÁRODNÍ ZÁRUKA

,

Záruka se poskytuje na dobu 2 roky. V případě že Zákon na ochranu spotrebitele dané země na izuje delší dobu, prodlužuje se záruka na tuto dobu.

Veškeré záru ní podmínky odpovídají Zákonu o ochran práv uživatel a jsou ízené zákonodárstvím státu, kde byl výrobek koupen. Záruka a bezplatná oprava se poskytuje v každém stát „kam jsou výrobky dodané spole ností „Saturn Home Appliances“ nebo jejím zplnomocn ným zástupcem a kde nejsou žádná omezení na dovoz nebo jiné právní p edisy omezující poskytnutí záru ního servisu a bezplatné opravy.

Pípady, na které se záruka a bezplatná oprava nevztahuje

1. Záru ní list je vypln n nesprávn .
 2. Výrobek byl poškozen kv li tomu,že zákazník nesplnil pravidla použití,která jsou uvedena v návodu.
 3. Výrobek byl používán k profesionálním, komer ním nebo pr myslovým cíl m (krom model speciáln ur ených pro tyto cíle,což je uvedeno v návodu).
 4. Výrobek má vn jší mechanická poškození nebo poškození,vyvolaná tím,že se dovnit dostala tekutina,prach,hmyz a jiné cizí p edm ty.
 5. Výrobek má poškození,která jsou vyvolaná nespln ním pravidel napájení od baterií,sít nebo akumulátor .
 6. Výrobek rozebírali, opravovali nebo m nili jeho konstrukci lidé, kte í nebyli zplnomocn ni k oprav , bylo provedeno samostatné išt ní vnit ních mechanizm a pod.
 7. Výrobek má p irozené opot ebov ání díl s omezenou dobou použití,spot ebních materiál atd.
 8. Výrobek má vrstvu usazeniny uvnit nebo zvenku termoelektrických oh íva , bez ohledu na kvalitu používané vody.
 9. Výrobek má poškození,která jsou vyvolaná p sobením vysokých (nízkých) teplot nebo ohn na termonestabilní ásti výrobku.
 10. Výrobek má poškozené p íslušenství a nástavce,které jsou dodané spolu s výrobkem (filtry, sí ky, sá ky,ba ky,misy,víka,nože, šleha e, struhadla,kotou e,talí e,trubky,hadice,kartá e a také sí ové š ry, sluchátkové š ry atd.).

V otázkách záručního servisu a oprav se obracejte na autorizovaná servisní střediska společnosti „Saturn Home Appliances“.

«Saturn Home Appliances»

«Saturn Home Appliances».

| | | | | - | LCD | | . |
|-------|-----|-------|---------------------------------------|---------------------------------------|-----|---|---|
| . | . | " " | 8-988-993-37-78 | + | + | + | + |
| 4 | . | , | 8(8553) 32-22-11 8-960-047-22-11 | + | + | + | + |
| 18 | . | . | 8(86133) 6-09-84, 8-918-215-57-75 | + | + | + | + |
| 98 | . | « - » | 8(3955) 67-00-44, 8(3955) 56-61-77 | + | + | + | + |
| 48, | 108 | " - " | 8(86152) 2-81-99 | + | + | + | + |
| . | . | - | 8(8182) 44-15-55 | + | | | |
| . | 1, | 1, | « -29» | 8(8512) 25-19-39 8(8512) 25-12-00 | + | | |
| . | . | 47 | « » | 8(8512) 54-67-67, 8(8512) 54-91-91 | + | + | |
| 16, 2 | . | 7 | « » | 8(85141) 3-61-25 | + | + | + |
| . | . | 15 | | 8-927-552-47-21, 8-937-122-13-99 | + | + | + |
| 32 | . | . | « » | 8(3852) 63-94-02 | + | + | + |
| . | . | .113 | | 8-905-425-60-4-73 | + | + | |
| . | . | .25 | | | | | |

| | | | | | | | | | |
|---|---|---------|----------|---------------------------------------|---|---|---|---|---|
| . | . | 37 | - | 8(8635) 47-47-72, 8(8635) 47-47-72 | + | + | + | + | + |
| . | . | .63 | « » | 8(86155) 3-11-00, 8-918-980-64-75 | + | + | + | + | + |
| . | . | 84 | . | 8(86559) 2-08-02, 8(86559) 5-29-71 | + | + | + | + | + |
| . | . | .58 | « » | 8(8442) 23-41-36, 8(937) 717-93-34 | + | | + | | |
| . | . | .173 | « » | 8(8442) 97-50-10, 8-960-883-59-00 | | + | | | |
| . | . | .4 | . | 8(8442) 98-16-47, 8(8442) 53-06-04 | + | + | + | + | + |
| . | . | - | « » | 8-961-688-53-48 | | + | | | |
| . | . | . | 9 | 8-927-521-52-00 | | + | | + | + |
| . | . | .32 | . | 8-937-722-68-12 | | | + | + | + |
| . | . | 158 | . | 8-937-730-66-03 | | + | | + | + |
| . | . | | | 8-904-404-14-55 | | | + | + | + |
| . | . | C 12/15 | «Master» | 8-928-126-63-66 | + | | + | | |
| . | . | 77- | « » | 8(937) 717-93-36 | + | | + | | |

| | | | | | | | | |
|----|----------|-------|---------------------------------------|---|---|---|---|---|
| 65 | , | | | | | | | |
| . | , | «» | 8(8172) 70-03-45, 8(8172) 54-21-54 | + | | + | + | + |
| . | , .65 | | | | | | | |
| . | , .1 | «» | 8(8172) 52-72-51 | + | | + | | |
| . | , .46 | " " | 8(473) 260-09-08, 8(473) 240-57-73 | + | | + | + | |
| . | , .140/1 | - . | 8(87951) 6-47-93, 8-928-654-28-01 | | + | | | |
| . | , .48 | «» | 8-962-655-20-00 | + | + | + | + | + |
| . | , .68 | «» | 8(8313) 21-14-14 | + | | + | | |
| . | , .54 | «» | 8(8313) 20-93-00, 8(8313) 20-92-94 | | + | | | |
| . | , .63 | " " | 8(84235) 2-86-59, 8(84235) 9-14-64 | + | | + | + | + |
| . | , .84 | «» | 8(86132) 2-11-71, 8(86132) 3-66-02 | + | + | + | + | + |
| . | , .64 | " " | 8(343) 240-26-60 | + | | + | | |
| . | , .16 | / " " | 8(343) 201-51-41, 8(343) 347-76-83 | + | + | + | + | + |
| . | , .47 | «» | 8(47467) 4-12-08, 8(47467) 4-33-17 | + | | + | | |

| | | | | | | | | | |
|---|-------------|----------|-------|--|---|---|---|---|---|
| . | , | . | « - » | 8(4932) 335185, 8(4932) 335236 | + | + | + | + | + |
| . | , .4 | | « - » | 8(3412) 30 79-79, 8(3412) 30-83-07 | + | | + | + | + |
| . | , .76 | | « - » | 8(3412) 78-76-85, 8(3412) 78-06-64 | + | | + | + | + |
| . | , .7/1, | 301, 307 | « - » | 8(3412) 44-60-40, 8(3412) 44-60-67 | | + | | | |
| . | , .7(« ») | 26» | « 26» | 8(86545) 2-74-74 | | + | | | |
| . | , .24 | | « » | 8(8362) 24-11-24, 8(8362) 25-55-40 | + | + | + | + | + |
| . | , .20 | | « » | 8(39520) 65-04-95, 8(39520) 93-16-56 | + | | + | + | |
| . | , .24 | | " " | 8(3952) 42-55-76, 8(3952) 78-15-83 | + | | + | | |
| . | , .38 | | « » | 8(843) 248-71-17, 8(843) 258-85-65 | + | | + | | |
| . | , .25, .47 | | « » | 8 (4842) 54-82-22, 8 (4842) 54-83-33 | + | + | + | + | + |
| . | , .33 | | - | 8(3439) 39-95-20, 8(34399) 34-74-40 | + | + | + | + | + |
| . | , .53/2 | | - | 8(3842) 35-39-67 | + | | | + | |
| . | , . | « - » | | 8(8332) 56-25-95, | + | | + | + | |

| | | | | | | | |
|---------------|-------|---|---|---|---|---|---|
| .42 | » | 8(8332) 54-70-77 | | | | | |
| , | - | 8-988-548-24-36 | + | + | + | | |
| , 9 | | | | | | | |
| , . 5 | « » | 8(4942) 300107, 8(4942) 300107 | + | | + | + | + |
| , . 2, | | 8(86142) 4-43-59 | + | + | + | + | + |
| , 3 | - | 8(861) 267-50-88 | + | + | + | + | + |
| , . 103, . 55 | « - » | 8(861) 222-64-13, 8(861) 222-85-55, 8-905-408-08-38 | + | + | + | + | + |
| , . 42/2 | | 8-918-041-31-04, 8(86131) 71-2-72 | | + | | | + |
| , . 116 | | 8(86164) 7-01-22 | | + | | | |
| , . 57 | " " | 8(86145) 3-78-74 | + | + | + | + | + |
| , . 25 | « » | 8(86164) 65-4-95, 8-918-355-81-70 | + | + | | + | + |
| , . 1 | | 8(86153) 4-16-70 | | + | | | |

| | | | | | | | |
|---------------------|------|--|---|---|---|---|---|
| , . , . | " " | 8(86151) 4-33-54, 8-918-464-00-86 | + | + | | + | + |
| , . , . 168 | " " | 8(3912) 93-54-33, 8(3912) 94-52-82 | + | + | + | + | + |
| , . , . 1 | « » | 8 (4712) 50-85-90, 8 (4712) 35-04-91 | + | + | + | + | |
| , . , . 36- , . 37- | « +» | 8 (86169) 7-39-99, 8(86169) 7-24-96 | + | + | + | + | + |
| , . , . 2 | « » | 8(4742) 33-45-65, 8(4742) 33-45-95 | + | + | + | + | + |
| , . , . 66 | " " | 8(8772) 52-36-90 | + | + | + | + | |
| , . , . 29 | « » | 8(8772) 55-62-38 | | + | | | + |
| , . , . 25 | « » | 8(8722) 93-30-73 | + | + | + | + | + |
| , . , . 20 | « » | 8(86385) 2-33-26 8-960-458-07-11 | + | + | | + | + |
| , . , . 11 | « » | 8 (499) 340-29-89, 8 (499) 733-25-00 | | + | | | |
| , . , . 16, . 9 | « » | 8(499) 717-82-07, 8(499) 717-82-12 | | | + | | |
| , . , . 1534 | « » | 8(495) 721-30-70, 8(499) 168-05-19, 8(499) 168-47-15 | + | | + | + | + |
| , . , . .3 (. .) | « » | | + | | + | + | + |

| | | | | | | | |
|-------------------------|-------|--|---|---|---|---|---|
| · · . , . 20 (30/05) | « » | 8(8552) 359002, 8(8522) 359042 | + | + | + | | |
| · · . , . 24 | " " | 8(8662) 42- 04-30 8(8662) 42- 12-21 | + | | + | + | |
| · · . , . 55 | « » | 8(86554) 5- 59-77, 8(86554) 3- 67-57 | + | + | + | + | + |
| · · . , . 9 (. « ») | « » | 8(8555) 48- 08-80, 8-917- 906-60-06 | + | | + | + | + |
| · · . , . 21 | « » | 8(831) 229- 63-66, 8(831) 229-60-87 | + | | + | + | |
| · · . , . 18 | « - » | 8(831) 46-18- 848 | | + | | | + |
| · · . , . 6 | « - » | 8(831) 46-18- 848 | | + | | | + |
| · · . , . 18 | « » | 8 (3843) 20- 31-33 | + | | + | + | + |
| · · . , . 14 | « - » | 8(8617) 63- 11-15, 8(8617) 63- 03-95 | + | + | + | + | + |
| · · . , . 17 | " - " | 8(383)274- 99-33, 8(383) 274-99-45 | + | | + | | |
| · · . , . 24 | | 8(86369) 3- 74-75, 8-928- 609-35-85 | + | + | + | | |
| · · . , . 4 | . . | 8 (3532) 36- 87-94 | + | | | + | + |
| · · . , . 16 | « - » | 8(3532) 77- 67-64 , 8(3532) 78- 15-82 | + | + | + | + | + |

| | | | | | | | |
|-------------------------------|--------|---|---|---|---|---|---|
| · · . , . 130 | " " | 8(3812)36- 42-02 | + | | + | + | + |
| · · . , . 2 | « - +» | 8(3537) 33- 84-43, 8(3537) 35- 13-18 | + | + | + | + | + |
| · · . , . 2 | « » | 8(8412) 26- 09-60, 8(8412) 26- 12-29 | + | | + | + | + |
| · · . , . 3, . | « - » | 8 (342) 221- 40-99 | + | + | + | + | + |
| · · . , . 11 | « - » | 8(8142) 78- 06-93, 8(8142) 70- 65-48 | + | | + | | |
| · · . , . 11 | « » | 8 (8112)-53- 86-30, 8 (8112)-53-86- 50 | + | | + | | |
| · · . , . 12 | | 8(793) 31-84- 16 | + | + | + | + | + |
| · · . , . 13 | " " | 8(8793) 98- 70-11 | + | + | + | + | + |
| · · . , . 148 | | 8(47396) 48- 911 | + | + | + | + | + |
| · · . , . 37 | « - » | 8(863) 250- 47-77 | + | | + | | |
| · · . , . 50- . 1/52, . 55 | « » | 8 (863) 21- 92-112, 8- 800-100-51- 52 | + | + | + | + | + |
| · · . , . 11 /17 | " . | 8-906-453- 35-81 | + | | + | | |

| | | | | | | | | |
|-----|------------|--------|---------------------------------------|---|---|---|---|---|
| . | , | | 8(4855) 22-04-77, 8(4855) 25-38-60 | + | + | + | + | + |
| . | , | " " | 8(86370) 2-19-50 | + | + | + | + | + |
| . | , | | 8(4855) 22-04-77, 8(4855) 25-38-60 | + | + | + | + | + |
| . | , | " " | 8(4855) 24-31-21 | + | + | + | + | + |
| . | , | | 8(4912) 76-88-01, 8(4912) 40-30-30 | + | + | + | + | + |
| . | , | " " | 8(4912) 41-33-02, | + | + | + | + | + |
| . | , | | 8(846) 931-85-46 | + | + | + | + | |
| 52, | . 8, 9 | | 8(846) 379-54-54 | + | + | + | + | + |
| . | , | " " | 8(812) 600-11-97 | + | + | + | + | |
| e | , | | 8(812) 325-36-56, 8(812) 325-36-57 | + | | + | + | |
| e | , | | 8(812) 822-18-00, 8(812) 320-06-61 | + | | | | |
| . | , 11, 36 , | " -95» | 8(8342) 23-05-91, 8(8342) 47-48-59 | + | + | + | | |
| . | , 1 | " -» | 8(8342) 23-05-91, 8(8342) 47-48-59 | + | + | + | | |

| | | | | | | | | | |
|---|---|--------------|----------|---|---|---|---|---|---|
| . | , | " -" | « - » | 8(8452) 35-11-80, 8(8452) 55-43-63 | + | + | + | + | + |
| . | , | . 167/1 | | 8-951-522-38-11 | + | + | + | + | + |
| . | , | . 253 | « » | 8(496) 547-04-95, 8(496) 549-32-79 | + | + | | + | + |
| . | , | . 90 | « » | 8 (8622) 55-51-19, 8 (8622) 55-01-08 | + | | | + | + |
| . | , | . 50 , . 8/1 | « » | 8(8652) 74-01-91 | + | + | + | | |
| . | , | . 63 | « » | 8(8652) 24-30-14, 8(8652) 23-31-81 | + | + | + | + | + |
| . | , | . 15 , . 21 | « » | 8(8652) 95-53-68, (8652) 95-61-90 | | + | | | |
| . | , | . , . 1 | « - » | 8 (4725) 24-62-27, 8 (4725) 24-73-49 | + | + | + | | |
| . | , | . 158 | « - » | 8(3473) 20-12-13, 8(3473) 20-27-70 | + | | + | + | + |
| . | , | . , . 25 | « » | 8(8212) 22-95-29, 8(8212) 29-12-20 | + | + | + | + | + |
| . | , | . 137 | « -2000» | 8(4752) 56-19-42, 8(4752) 56-19-44 | + | + | + | + | + |
| . | , | . 88/15 | - | 8-910-834-80-35, 8-952-065-89-10 | + | | + | | |

| | | | | | | | |
|---------------------------|-------|--|---|---|---|---|---|
| ., . .24/2 | | 8(86130) 4-86-59, 8-918-147-02-03 | + | + | | + | + |
| ., . .2/2 | " " | 8(86196) 7-20-53 | + | + | + | + | + |
| ., . .48 | « +» | 8(8482) 22-72-41, 8(8482) 22-71-85, 8(8482) 61-65-64 | + | + | + | + | + |
| ., . .58 | « -2» | 8(3822) 56-23-35, 8(3822) 48-08-80 | + | | + | | |
| ., . .137 | « -» | 8(4872) 31-12-57 | + | + | + | + | + |
| ., . .55 | " " | 8(3452) 47-35-69 | + | | + | + | + |
| ., . .28 | « » | 8(3012) 21-89-63 | + | | + | + | + |
| ., . .18, 18, 2 | « » | 8(8422) 31-00-00 | + | + | + | + | + |
| ., . .16/7 | « » | 8(8422) 73-44-22, 8(8422) 73-29-19 | + | + | | + | + |
| ., . .378 | « -» | 8(87875) 7-44-82 | + | + | + | | |
| ., . .148 | « -» | 8(3472) 77-12-62 | + | | + | | |
| ., . 153, .42, 7 | « » | 8(347) 279-90-70, 8(347) 241-62-02 | | | | | + |
| ., . .15 | " " | 8(86391) 2-18-06 | + | | + | | |

| | | | | | | | |
|----------------------|--------|--|---|---|---|---|---|
| ., . 36 | « » | 8(8352) 62-30-97, 8(4942) 63-20-98 | + | | + | | |
| ., . .102 () | | 8(351) 772-72-05, 8(351) 772-73-66, 8(351) 772-69-01 | + | + | + | + | + |
| ., . .8 () | | 8(351) 239-39-34, 8(351) 239-39-35 | + | + | + | + | + |
| ., . .18 | « » | 8(8202) 54-31-88 | + | | + | + | + |
| ., . .340" " | « -» | 8(8782) 27-30-60, 8(8782) 27-70-77 | + | + | + | + | + |
| ., . .48, . 11 | " . ." | 8(8782) 25-04-66, 8(8782) 25-19-15 | + | + | + | + | + |
| ., . .1 | " " | 8-904-345-83-18 | + | + | + | + | + |
| ., . .21 | « » | 8 (84722) 9-52-07, 8-937-469-52-07 | + | + | + | + | + |
| ., . .57 | « -» | 8(8453) 55-80-89, 8-964-848-45-06 | + | | + | + | + |
| ., . .12 | « -» | 8 (4852) 25-94-83 | + | | + | | |

2

«Saturn Home Appliances»

«Saturn Home Appliances».

| | | | | / | - | - |
|----|------------------------|-------|---|---|---|---|
| 1 | , . , 36 | Hi-Fi | (064) 424-89-50 | + | + | + |
| 2 | , . , 14 | | (065) 632 21 83, 050-904-57-17 | + | + | + |
| 3 | , . , 66 | | 062744-60- 38(39) | + | + | + |
| 4 | , . , 49 | - | (04563) 633-19 | - | + | - |
| 5 | . 50- , 82 | - | (045) 63-68-413 | + | + | + |
| 6 | , . , 57 | | (041) 43-406-36 | + | + | - |
| 7 | , . , 43 | " " | (0314 1) 43-432 | + | + | + |
| 8 | , 3, . 8 | - | (044) 332-01-67 | + | + | + |
| 9 | , . , 42 | - | (0432) 46-50-01 | + | + | - |
| 10 | , . , 61 | | (0432) 61-95-73 | + | + | + |
| 11 | , . , 16 | - | (0432) 464393; (0432) 468213 | + | + | + |
| 12 | , . , 3 | | (0432) 64-24- 57, (0432) 64-26-22 | + | + | + |
| 13 | , . , 1 | | (0432) 509-191, 579-191 | + | + | + |
| 14 | , . , 68, 1 , . 420 | . | (0562) 337-574 | + | + | + |
| 15 | , . , 17 . 130 | - | (056) 778-63-25 (28) | + | + | + |
| 16 | , . , 59 | | (0562) 35-04-09 | + | + | + |

| | | | | | | |
|----|----------------|-----|------------------------------------|---|---|---|
| 17 | , .118 | | (0562) 67-60-44 | + | + | + |
| 18 | , .41 | | (056) 790-04-60 | + | + | + |
| 19 | , .9 | | (068) 851-33-33 | + | + | + |
| 20 | , -. 188 | | (062) 3450607 0953204451 | + | + | + |
| 21 | , .129 | - | (062) 349-26-81 | + | + | + |
| 22 | , .1 | - | (062) 3027569 (066) 5082652 | + | + | + |
| 23 | , .8 | " " | (0412) 471-568 | + | + | - |
| 24 | , .4 .222 | | (067) 410 2198 | + | + | + |
| 25 | , 24 | C | (0412) 47-07- 42, 42-11-53 | + | + | - |
| 26 | , .50 | - | (061) 220-97-65 (64) | + | + | + |
| 27 | , .175 | | (061) 701-65-96 | + | + | + |
| 28 | , .83 | - | (061) 212-03-03 | + | + | + |
| 29 | , .75 | | 066-085-75-39 | + | + | + |
| 30 | -, .19 | | (0342) 559-525, 750-777 | + | + | + |
| 31 | -, .14 | | (0342) 754737 | + | + | - |
| 32 | , .9 | - | 096-729- 4038, 067-484- 9888 | + | + | + |
| 33 | , .76 | | (04597) 57393 | + | + | - |

| | | | | | | |
|----|-----------------|-----|--|---|---|---|
| 34 | , .161 | - | (04736) 629-49 | + | + | + |
| 35 | , 1 | - | (044) 591-11-90 | + | + | + |
| 36 | , .1 | " " | (044) 4269198 | + | + | - |
| 37 | , .9 57 | - | (044) 369-5001 (063) 486-6999 | + | + | + |
| 38 | , .10 | | (06272) 2-62- 23, (050) 279-68-16 | + | + | + |
| 39 | , .1 | " " | (0522) 301-456 | + | + | + |
| 40 | , .2 | | (0522) 35-79-23 | + | + | + |
| 41 | , .98 | - | (0522) 270- 345, 349-585 | + | + | + |
| 42 | , .13 | | (097) 264-21- 67, 776-67-70 | + | + | + |
| 43 | , .3, .5 | " " | (04142) 5-05-04 | + | + | + |
| 44 | , .15-106 | . | (06264) 5-93-89 | + | + | + |
| 45 | , .7 | | (050) 526-06-68 | + | + | + |
| 46 | , .44, .1 | | (05366) 39-192 | + | + | - |
| 47 | , .42 | | (056) 401-33- 56, 404-00-80, 474-61-03 | + | + | + |
| 48 | , .9 | | (056) 4092302 03 | + | + | + |
| 49 | , .64/7 | | (0564) 40-07-79 | + | + | + |
| 50 | , .73 | " " | (056) 440-07-64 | + | + | + |
| 51 | , .81 | | (050) 214-91- 73; (066) 017- 02-03 | + | + | + |
| 52 | , .49 | - | (0642) 505-783 | + | + | + |

| | | | | | | |
|----|---------------------|------|--|---|---|---|
| 53 | , 50 | | (0642)50-57-83 | + | + | + |
| 54 | , . . , 96 | | (0642) 494-217, 33-11-86 | + | + | + |
| 55 | , . , 1 | - | (0332)290752 | + | + | + |
| 56 | , . , 15 | | (032) 244-53-44 | + | + | + |
| 57 | , . , 35 | " " | (032) 2973631 | + | + | + |
| 58 | , . , 2 | | (032) 247-14-99 | + | + | + |
| 59 | , . , 116 | " -" | (032) 245-80-52 | + | + | - |
| 60 | , . , 28 | | (032) 239-51-52 (032) 239-55- 77,295-50-28, 295-50-29 | + | + | + |
| 61 | , . , 9 | " " | 032-267-63-26 | + | + | - |
| 62 | , . , 242 | | (062)322-55-50 | + | + | + |
| 63 | , . , 2 | - | 04337- 64847;0432- 468213 | + | + | + |
| 64 | , . , 24/1 | | (099) 262-11-18 | + | + | + |
| 65 | , . , 46 | | (03131)37-337, 37-336 | + | + | - |
| 66 | , . , 50 , 32/18 | | (0629) 41-06-50 | + | + | + |
| 67 | , . , 227 | " -" | (0629) 473-000 | + | + | + |
| 68 | , . , 33, | " -" | (0512) 580-555 | + | + | + |

| | | | | | | | |
|----|-----|---------------|--------|---|---|---|---|
| 69 | , . | 49 | " " | 0512-58-21-80 | + | + | + |
| 70 | , . | 2 | | (0512) 58-06-47 | + | + | + |
| 71 | , . | 62 | - | (05662) 22-488, (097) 402-71-95 | + | + | - |
| 72 | , . | 97, 2 | " , -" | (05662) 4-15-03 | + | + | - |
| 73 | , . | 38 | - . | (055) 497-26-17 | + | + | - |
| 74 | , . | 38 | " " | (041)4152010 | + | + | - |
| 75 | , . | 66 (.) 2 | | 048-7317704; 7317703; | + | + | + |
| 76 | , . | 90 | | (048) 700 17 37 | + | + | + |
| 77 | , . | 55 | " " | (048) 715-10- 25, (0482) 39- 06-18 | + | + | + |
| 78 | , . | 67 | " " | 8(05632) 6-15- 54, (05632) 6- 23-42 | + | + | - |
| 79 | , . | 26 | | 050-013-72-17, 0532-509889 | + | + | + |
| 80 | , . | 14 | | (0532) 69-42-62 | + | + | + |
| 81 | , . | 21 | - | (0532) 69-09-46 (093)562-81-25 | + | + | + |
| 82 | , . | 66 | | (0532)615-621 | + | + | + |
| 83 | , . | 371 | - | (04637)53-982 (093)753-38-28 | + | + | + |
| 84 | , . | 101/1 | | (046) 3738595 | + | + | + |
| 85 | , . | 12 | - | (0362) 26-67- 53,26-65-85 | + | + | - |

| | | | | | | |
|-----|---------------|--------------|---------------------------------|---|---|---|
| 86 | , . 26 | | (0692) 55-56-43, 45-36-99 | + | + | + |
| 87 | , . 72 | - | (0652)-69-07-78 | + | + | + |
| 88 | , . 17/1 | " - " | (0652) 522-771 | + | + | + |
| 89 | , . 32 | - | (04733)-46-182 | + | + | - |
| 90 | 15 (, .) | | (06444)40289 | + | + | + |
| 91 | , . 171 /10 | - | (245) 53-136 | + | + | + |
| 92 | , . , 19 | | (0542) 705-296 | + | + | - |
| 93 | , . , 17 | SLT- Service | (0542) 78-10-13 | + | + | + |
| 94 | , . , 2 | " " | (0352) 26-30-13, 23-17-97 | + | + | - |
| 95 | , . 1/24 | " " | (047) 44-46-614,(047) 44-46-134 | + | + | + |
| 96 | , . , 101 | | (0312) 661-297 | + | + | + |
| 97 | , . , 12 | | (057) 717-13-39, 702-16-20 | + | + | + |
| 98 | , . , 3 | | (057) 734-97-24, 712-51-81 | + | + | - |
| 99 | 18 (, -) 42 | " " | (096) 595-37-46 | + | + | + |
| 100 | , . , 1 | | (03142) 42-258 | + | + | + |
| 101 | , . , 5 | | (0552) 29-60-42 | + | + | + |
| 102 | , . , 28 | | (0552) 43-40-33 | + | + | + |
| 103 | , . , 35 | | (0552) 420-235 | - | - | + |
| 104 | , . , 18 | | (0382)78-37-55, 78-37-73 | + | + | + |

| | | | | | | |
|-----|------------------|-------|--|---|---|---|
| 105 | , . , 10/1 | - | (0382) 723-241, 723-240 | + | + | + |
| 106 | , . , 63 | | 097-549-20-36 | + | + | + |
| 107 | , . , 7, . 301 | | 0472-633-728 | + | + | + |
| 108 | , . , 71 | | (0472) 435-389 | + | + | + |
| 109 | , . , 146, . 102 | " - " | (0472) 563-478, 500-354, (096) 505-63-63 | + | + | + |
| 110 | , . , 77- , 1 | | (0462) 601585 | + | + | + |
| 111 | , . , 6 | | (0462) 724872,724949 | + | + | + |
| 112 | , . , , 105 () | | (0372) 55-48-69,90-13-11 | + | + | + |
| 113 | , . , 265 | | (0372) 58-43-01 | + | + | + |
| 114 | , . , , 3 | " - " | (050) 373-73-71 | + | + | + |
| 115 | , . , 5 (.) | | (050) 324-43-01 | + | + | - |

GB

WARRANTY COUPON

RU

When purchasing the product,
please require its checking before you;

BE SURE

that the goods sold to you, are functional and complete
and that the warranty coupon is filled in correctly.

This warranty coupon confirms the absence of any defects in the product you purchased
and provides for free of charge repair of the product failed through the fault of the
manufacturer throughout the period of warranty service and free of charge repair.

Failing the presentation of this coupon, in case of its improper filling in, infringement of
factory seals (if any), and also in cases indicated in the warranty obligations, the claims are
not accepted, and no warranty service and free of charge repair is made!

The warranty coupon is valid only in the original copy with the stamp of trading
organization, signature of the seller, date of sale and signature of the buyer.

CZ

ZÁRU NÍ LIST

UA

P i koupí výrobku
žádejte o jeho vyzkoušení ve Vaší p ítomnosti,
P ESV D TE SE,
že Vám prodaný výrobek je dob e fungující a kompletní
a že záru ní list je vypln n správn .

Tento záru ní list potvrzuje, že na Vámi koupeném výrobku nejsou žádné vady a zajiš uje
bezplatnou opravu nefungujícího p ístroje z viny výrobce, b hem celé záru ní doby.

Bez p edložení tohoto listu, p i jeho nesprávném vypln ní, porušení plomb výrobce (jsou-
li na výrobku) a také v p ípadech, které jsou uvedené v záru ním list , nároky se
nep ijímají a záru ní oprava se neprovádí!

Záru ní list je platný jenom jako originál s razítkem obchodní organizace, podpisem
prodavá e, termínem prodeje a podpisem zákazníka.



WARRANTY COUPON

ZÁRU NÍ LIST

SATURN HOME APPLIANCES S.R.O. KON VOVA 141, 13083
PRAHA 3 – ŽIŽKOV, ESKÁ REPUBLIKA, TEL: + 4202/ 67 108 392

Model /

Production number/Výrobní íslo/
/

Date of sell/Termín prodeje/ / ,



Shop stamp/Razítko obchodu/ /




Seller's signature/Podpis prodava e/ /



Buyer's Signature confirming the acquaintance and consent with conditions
of free of charge maintenance service of the product, and absence of the
complaints on appearance and color of the product.

Podpis zákazníka, potvrzující seznámení a souhlas s podmínkami
bezplatného záru ního servisu výrobku, a také neexistence nárok na
vn jšek a barvu výrobku.



| Saturn® | | Saturn® | | Saturn® | | Saturn® | |
|------------------------------|---|------------------------------|---|------------------------------|---|------------------------------|---|
| Model / | / |
| Production number / | / |
| Name of the Trade Company / | | Name of the Trade Company / | | Name of the Trade Company / | | Name of the Trade Company / | |
| Stamp of the Trade Company / | | Stamp of the Trade Company / | | Stamp of the Trade Company / | | Stamp of the Trade Company / | |
| Client Address/Phone # / | | Client Address/Phone # / | | Client Address/Phone # / | | Client Address/Phone # / | |
| Date of Receiving/ / | | Date of Receiving/ / | | Date of Receiving/ / | | Date of Receiving/ / | |
| Defect / / | | Defect / / | | Defect / / | | Defect / / | |
| Signature, Stamp / , / | | Signature, Stamp / , / | | Signature, Stamp / , / | | Signature, Stamp / , / | |
| COUPON 1 | | | | | | | |
| COUPON 2 | | | | | | | |
| COUPON 3 | | | | | | | |